



$$V_{OUT} = ((I_{LOAD} * R_{SENSE}) * GAIN) + V_{REF}$$
$$GAIN=1000V/V$$



AE01001212		
-		
-		
-		
astroelectronic		
Sheet: /		
File: ZXCT212.kicad_sch		
Title: 26V, Zero-Drift, High-Precision Current Monitor. 1000V/V.		
Size: A4	Date: 2025-06-23	Rev: 1
KiCad E.D.A. 9.0.2	Id: 1/1	