



$$V_{OUT} = ((I_{LOAD} * R_{SENSE}) * GAIN) + V_{REF}$$

$$GAIN=100V/V$$



AE01001214		
-		
-		
-		
astroelectronic		
Sheet: /		
File: ZXCT214.kicad_sch		
<b>Title: 26V, Zero-Drift, High-Precision Current Monitor. 100V/V.</b>		
Size: A4	Date: 2025-06-23	Rev: 1
KiCad E.D.A. 9.0.2	Id: 1/1	