

## Directions For Users With CID 15 Samsung eMMC

1. Download [EMMC\\_15\\_Root\\_Bootloader\\_Unlock\\_S5\\_QB2\\_PB1.zip](#)

2. Unzip

Copy the following to your External SD card:

RootS5 Folder,

EMMC\_15\_SafeStrap\_QA1\_6\_0\_1\_MM\_Bootloader\_Unlock\_A IO.zip,

and [EMMC\\_15\\_VZW\\_QB2\\_STOCK\\_MAGISK\\_ROOT.zip](#)

3. Reboot Phone to Download Mode (Pwr +Vol Dwn+Home)

4. Use Odin 3.12 and load the

COMBINATION\_VZW\_FA44\_G900VVRU2APA1\_VZW2APA1\_257265

6\_REV00\_user\_mid\_noship\_MULTI\_CERT.tar.md5 firmware in the AP Slot

5. Flash and let the phone reboot. It will reboot to recovery and finish install then it will reboot and take about 20 seconds to boot.

6. **If you do not have an External SD Card**, copy the following NOW to your Internal Storage:

EMMC\_15\_SafeStrap\_QA1\_6\_0\_1\_MM\_Bootloader\_Unlock\_A IO.zip,

and [EMMC\\_15\\_VZW\\_QB2\\_STOCK\\_MAGISK\\_ROOT.zip](#)

7. Use the File Manager in the app drawer of the phone and install **Apex\_Launcher.apk** press home button and set Apex as the default launcher.

Install **Superuser.apk**, **Busybox.apk** and **SafeStrapKK.apk** . Do not open anything yet.

8. Now Install **tr\_v2.apk**.

Open TowelRoot and **CLICK MAKE IT RAIN** . It should tell you you have succeeded.

9. Now Open **Superuser app** and click "New User" to install it.

Once done, open SuperSU and update the SU binaries using the "NORMAL" method. It will tell you you need to reboot. You can skip doing this. (If the Superuser install hangs for more than 5 minutes reboot phone and try to install it again.)

10. Now open the **BusyBox app**, grant SuperSU access and install BusyBox.

11. Now open **SafeStrap**, grant SuperSu access and click "install recovery". If the SafeStrap recovery fails to install, make sure BusyBox is installed by rerunning the BusyBox app (it will tell you if BusyBox is installed) if not click "install" again, reboot phone and open SafeStrap and try to install recovery again

12. Once SafeStrap Recovery is installed click "reboot to SafeStrap Recovery".

13. Once in SafeStrap Recovery choose install and select:

[EMMC\\_15\\_SafeStrap\\_QB2\\_6\\_0\\_1\\_MM\\_Bootloader\\_Unlock\\_A IO.zip](#)

14. Install the zip. The phone will power off. Reboot the phone to TWRP Recovery with Pwr+VolUp+Home

15. You will now have an Unlocked Bootloader and TWRP recovery Installed. Now whoose Wipe > Advanced Wipe. Select Dalvik Cache; Data; System; Cache, and swipe the swipe to wipe bar. When done, click the back button, click Install, and choose:

[EMMC\\_15\\_VZW\\_QB2\\_STOCK\\_MAGISK\\_ROOT.zip](#)

You're done! You will have stock rooted Marshmallow QB2 Build installed with an unlocked bootloader and custom recovery.