



Instructions: Solder "SELF" together. Program using another tinyISP programmer.  
 Once programmed, unsolder and solder reg together.  
 Don't forget to flash and fuse!