



## Before

- **Must** check that path underneath the saw is clear (no table, floor, etc)
- **Should not** plunge into workpiece unless necessary (kickback)
- **Must** remove riving knife for plunge cut
- **Must** check blade height
- Think about your setup once the cut-off is removed (can it tip/fall?)

## During

- **Must** make sure the rail can't slide

## After

- Put Festool saw back into systainer and underneath the chop saw

