

Danny Andersen



0V, 3v3, 5V, GPIO, IO1	Sockets
240V in, From T/F, RELAY, To T/F	Screw Terminals x2
Fuse	0.2A
Vero Board	qty 1
Q1	AMS1117 3v3 Buck converter
R1, R4	1K
R2	330Ω
R3	qty 1