



To enable Bandpass  
cut EN\_Filter  
and populate  
Components

For 3 Stage  
Amp populate  
R17 + R18,  
cut S2\_EN 1/2  
and solder 2/3

derGraph

EN\_Filter2

C4 R9

R10 C3 R18

R7 C2 R6

EN\_Filter1

Rev 1

Sheet:		
File: anemometer.kicad_pcb		
Title:		
Size: A4	Date:	Rev:
KiCad E.D.A. kicad 7.0.5		Id: 1/1