

TOTALS	METRES	SPITS	DIGS
	3853	81	38

project	sheet	location	metres	spit	dig	mandrel	rrp_status	comments_other
JTS-002	001-003	002-003	189	2	0	40	SUCCESS	spit water used to flush duct
JTS-002	034-035	107-106	54	4	2	40	SUCCESS	spit water used to flush duct
JTS-002	34	110-107	153	2	1	40	SUCCESS	Had to do a dig up to find the pit
JTS-002	034-035	107-106	54	4	2	40	SUCCESS	spit water used to flush duct
JTS-002	003-005	003-005	208	3	1	40	SUCCESS	spit water used to flush duct
JTS-002	099-100	052-053	90	2	0	60	SUCCESS	spit water used to flush duct
JTS-002	050-060	207-208	78	2	0	60	SUCCESS	spit water used to flush duct
JTS-002	005-008	004-007	295	6	3	40	SUCCESS	spit water used to flush duct
JTS-002	042-043	125-124	138	3	2	28	SUCCESS	blockage at several locations. Dug down and spit watered to clear
JTS-002	21-24	031-034	203	3	1	28	SUCCESS	blockage at several locations. Dug down and spit watered to clear
JTS-002	136-138	325-329	145	3	2	40	SUCCESS	blockage at several locations. Dug down and spit watered to clear
JTS-002	136-138	324-325	153	4	2	40	SUCCESS	blockage at several locations. Dug down and spit watered to clear
JTS-002	044-046	150-151	151	3	2	32	SUCCESS	blockage at several locations. Dug down and spit watered to clear
JTS-002	147-148	366-367	177	3	2	32	SUCCESS	Left the two dig up holes open as a pit needs to be installed as copper has been pulled up between the blockages
JTS-002	133-134	321-322	118	3	1	32	SUCCESS	spit water used to flush duct
JTS-002	131-133	320-321	114	3	1	32	SUCCESS	Pit at location 321 needs upgrading
JTS-002	140-155	329-341	185	5	5	40	SUCCESS	Had to do a dig up to find a buried pit. Left it with a witch hat on top of pit
JTS-002	144-147	364-365	231	4	2	50	SUCCESS	blockage at several locations. Dug down and spit watered to clear
JTS-002	152-153	369-370	99	3	1	40	SUCCESS	blockage at several locations. Dug down and spit watered to clear
JTS-002	140-155	329-328	162	3	2	40	SUCCESS	blockage at several locations. Dug down and spit watered to clear
JTS-002	144-147	364-365	235	4	2	40	SUCCESS	blockage at several locations. Dug down and spit watered to clear
JTS-002	155-158	328-327	163	3	2	40	SUCCESS	blockage at several locations. Dug down and spit watered to clear
JTS-002	158	327-326	100	1	0	40	SUCCESS	spit water used to flush duct
JTS-002	167-168	346-347	68	4	2	28	SUCCESS	Was tight going around the bends
JTS-002	168-169	347-348	84	2	0	32	SUCCESS	spit water used to flush duct
JTS-002	080-084	231-245	206	2	0	60	SUCCESS	spit water used to flush duct
			3853	81	38			