



Mounting holes are for M3 screws and should be drill at 2.5mm (#39) and tapped at .5mm threads.

Additional support for the two corners without mounting holes may be needed in high vibration environments.