

	Before	During	After
overflow	B=0 U=100 RX=100	B=100 U=0 RX=100	B=100 U=0 RX=100
state	B=0 U=100 RX=100	B=0 U=100 RX=100	B=0 U=100 RX=100
replay	B=0 U=100 RX=99	B=100 U=0 RX=99	B=100 U=0 RX=99
calib	B=0 U=100 RX=100	B=100 U=0 RX=100	B=100 U=0 RX=100