

Gourmetop

Magnetic Knife strip

Assembly & Mounting Instruction

support@gourmetop.com




Parts Included

- A. 1x Magnetic Knife Strip
- B. 2x Wood Plugs



Adhesive Mounting Kit

- C. 2x Machine Screws
- D. 2x Adhesion Tapes
- E. 1x Philips Screwdriver (An accessory only be used for adhesive mounting)



Drill Mounting Kit

- F. 2x Plastic Screw Anchors
- G. 2x Drywall Screws



Adhesive Mounting For Refrigerators & Tiles

1. Pick a suitable spot

Find a suitable area to mount. Clean the area with a clean towel to remove dust & oil before installation. Make sure the spot is accessible for you but not for your children.

2. Mark the spot

Use a level to mark the area where you want to hang the magnetic holder with a pencil or marker.

3. Align the protruding part of the adhesive tapes(D) with the holes on the magnetic knife strip(A), and insert it.



4. Use the Phillips Screwdriver (E) to screw the adhesive tape(D) into the Strip(A)



Adhesive Mounting For Refrigerator & Tiles

5. Pull Out the Plastic Separator from the tapes(D)



6. Press the knife strip(A) directly on the selected area for 30 seconds or more.



7. Use the Phillips Screwdriver(E) to unscrew the knife strip(A) from the wall.



Adhesive Mounting For Refrigerator & Tiles

8. Use fingers to push out all air from the tapes(D).



9. Use the Philips Screwdriver(E) to remount the knife strip(A) with screws(C), insert the wood plugs(B), then you are all set



Warning: Do not overtighten the screws, as this may cause them to strip, leading to air buildup within the adhesive tapes. This can prevent the tapes from adhering securely to the wall.

Gourmetop

Magnetic Knife strip

Assembly & Mounting Instruction

support@gourmetop.com



Parts Included

- A. 1x Magnetic Knife Strip
- B. 2x Wood Plugs



Adhesive Mounting Kit

- C. 2x Machine Screws
- D. 2x Adhesion Tapes
- E. 1x Philips Screwdriver (An accessory only be used for adhesive mounting)



Drill Mounting Kit

- F. 2x Plastic Screw Anchors
- G. 2x Drywall Screws



Drill Mounting For Stucco, Wood, Stone & Tiles

1. Determine a desired location

Mark 2 insertion points on the wall as the diagram illustrated. You may need to double verify that the dimensions are correct - measure on the actual product and see if they match.



2. Drill Holes

Use a stud-finder to determine if there is a wall stud located at either insertion mark. If a mark does align, use a drill to drill a hole in the 2 insertion points.



Drill Mounting For Stucco, Wood, Stone & Tiles

3. Hammer anchors(F) into the holes



4. Screw drywall screws(G) through the knife strip(A) and anchors(F), insert the wood plugs(B). Then, you are all set.



Care Instruction:

- Dust often with a soft, dry cloth.
- Avoid using abrasives or strong-chemical cleaners as they may damage the finish of the product.

Warning:

- STRONG MAGNETS. Handle with care when installing the magnetic bar. Can be harmful to people with pacemaker or metallic implants. THIS IS NOT A TOY.

Thank you for your purchase!

All our products are under **One-Year Warranty**, please feel free to contact us by email support@gourmetop.com