

## Robot arm installation

**First** place the Base

**Second**, put the Waist above the base

**Third**, connect Arm 1 on the Waist

**Fourth**, tie Arm 2 on top of Arm 1

**Fifth**, install Gripper on top

