



Note: A spacer is required between plug and PCB to maintain proper PCB insertion depth of the wall plug and the offset for enclosure design