

Tips

1. Do not do anything once you found the Raspberry Pi is trying to download the 'lid' file from logger.
2. Make sure to use direct power to connect raspberry pi, do not use the laptop battery power, because the battery power is not strong enough
3. We don't need the long bolts, we need short one.
4. Remember to clean the 'towifi' folder on raspberry pi. Delete all files in that folder
5. **Ask captain to share wifi hotspot**
6. **Double check crontab -e**
7. **Change the control file to normal fishing,(logger name,time depth psi)**
8. **Add a space on 'getmap.py' on AP3 data transmitting after 'ylb' while using 2018 New AP3 transmitter**
9. Buy extension cable on the road
10. Reset logger to every 90 or 60 or 120 seconds interval before make the trip(GMT time,set your pc to gmt time)
11. Make sure your raspberry pi is gmt time
12. If need an installation, charge the battery both, logger and drill
13. Reset ap3 to make it not sleep