

PRE-FLIGHT

PARKING BRAKE.....SET
FLAPS.....RETRACTED
SPOILERS.....DISARMED/RETRACTED
ENGINE MASTERS.....BOTH OFF
ENGINE MODE SELECTOR.....NORMAL
THRUST LEVERS.....IDLE
LANDING GEAR LEVER.....DOWN
WIPERS.....OFF
ANTI-SKID.....ON
TRANSPONDER MODE.....STBY

COCKPIT PREPARATION

BATTERIES.....BOTH ON
ELECTRICAL POWER.....EXT OR APU
ADIRS.....NAV
CREW SUPPLY.....ON
INST/DSPL BRIGHTNESS.....AS REQUIRED
NAV & LOGO LIGHTS.....ON
EMERGENCY LIGHTS.....ARMED
NO SMOKING SIGNS.....AUTO
RADIO PANELS.....BOTH ON

BEFORE START

WINDOWS/DOORS.....CLOSED/LOCKED
SEATBELT SIGNS.....ON
FUEL QUANTITY.....CHECKED
BARO REFERENCE.....SET
TAKEOFF DATA.....REVIEWED
APU.....ON
APU BLEED.....ON
EXTERNAL POWER.....DISCONNECTED/OFF
FUEL PUMPS.....ON
THRUST LEVERS.....IDLE
BEACON LIGHTS.....ON

AFTER START

PARKING BRAKE.....SET
ENGINE MODE SELECTOR.....NORMAL
APU BLEED.....OFF
APU.....OFF
AUTOBRAKES.....MAX
SPOILERS.....CHECKED/ARMED
FLAPS.....SET T/O
RUDDER TRIM.....ZERO
PITCH TRIM.....SET
FLIGHT CONTROLS.....CHECKED
ANTI-ICE.....AS REQUIRED
ECAM STATUS.....CHECKED
T/O CONFIG.....NORMAL
NOSE LIGHT.....TAXI
RWY TURNOFF LIGHTS.....AS REQUIRED

BEFORE TAKE-OFF

CABIN CREW.....ADVISED
BRAKE TEMPERATURE/FANS...CHECKED/OFF
ENGINE MODE SELECTOR.....AS REQUIRED
TRANSPONDER MODE.....ON
TCAS.....TA/RA, ABV
PREDICTIVE WINDSHEAR.....AUTO
PACKS.....AS REQUIRED
RWY TURNOFF LIGHTS.....ON
NOSE LIGHT.....T/O
LANDING LIGHTS.....ON
STROBE LIGHTS.....ON
ECAM MEMO.....TAKEOFF NO BLUE

AFTER TAKE-OFF

NOSE LIGHT.....OFF
RWY TURNOFF LIGHTS.....OFF
ENGINE MODE SELECTOR.....NORMAL
SPOILERS.....DISARMED
FLAPS.....RETRACTED
LANDING GEAR.....UP/LIGHTS OFF
PACKS.....BOTH ON
ANTI-ICE.....AS REQUIRED

CRUISE

ANTI-ICE.....AS REQUIRED
BARO REFERENCE.....STD
LANDING LIGHTS.....OFF
WING LIGHTS.....AS REQUIRED
SEATBELT SIGNS.....AS REQUIRED

APPROACH

TCAS.....BLW
SEATBELT SIGNS.....ON
BARO REFERENCE.....__SET
WEATHER INFORMATION.....RECEIVED
LANDING DATA.....REVIEWED
ANTI-ICE.....AS REQUIRED
LANDING LIGHTS.....ON

LANDING

CABIN CREW.....ADVISED
LANDING GEAR.....DOWN/3 GREENS
FLAPS.....SET LDG
SPOILERS.....ARMED
AUTOBRAKES.....__SET
ENGINE MODE SELECTOR.....AS REQUIRED
RWY TURNOFF LIGHTS.....ON
NOSE LIGHT.....TAXI
GO AROUND ALTITUDE.....__SET
ECAM MEMO.....LANDING NO BLUE

AFTER LANDING

BRAKE FANS.....AS REQUIRED
ENGINE MODE SELECTOR.....NORMAL
LANDING LIGHTS.....OFF
NOSE LIGHT.....TAXI
RWY TURNOFF LIGHTS.....AS REQUIRED
STROBE LIGHTS.....OFF
FLAPS.....RETRACTED
SPOILERS.....DISARMED/RETRACTED
TRANSPONDER MODE.....STBY
TCAS.....STBY
PREDICTIVE WINDSHEAR.....OFF
ANTI-ICE.....AS REQUIRED
APU.....ON

PARKING

PARKING BRAKE.....SET
APU BLEED.....ON
ENGINE MASTERS.....BOTH OFF
FUEL PUMPS.....OFF
BEACON LIGHTS.....OFF
NOSE LIGHT.....OFF
RWY TURNOFF LIGHTS.....OFF
SEATBELT SIGNS.....OFF
ANTI-ICE.....OFF
EXTERNAL POWER.....ON IF AVAIL
 APU BLEED.....OFF
 APU.....OFF

SECURING THE AIRCRAFT

BRAKE FANS.....OFF
RADIO PANELS.....BOTH OFF
EMERGENCY LIGHTS.....OFF
NO SMOKING SIGNS.....OFF
NAV & LOGO LIGHTS.....OFF
CREW SUPPLY.....OFF
ADIRS.....OFF
INST/DSPL BRIGHTNESS.....MINIMUM/OFF
APU BLEED.....OFF
APU.....OFF
EXTERNAL POWER.....DISCONNECTED/OFF
BATTERIES.....OFF

