



CUSTOM SOLUTIONS LLC®

DESIGNED WITH YOU IN MIND

Thank you for purchasing the Connect Chair from Custom Solutions! We greatly appreciate your support of American manufacturing. To ensure long term comfort and reliability, please follow the assembly directions carefully.

Before we get started, please ensure you have the following tools:

Phillips Screwdriver & 5mm Allen Wrench (included in pack)

Note: 3mm Allen Wrench (included) is required for the optional headrest.

1. Remove all contents from box. **Interior boxes contain hardware, casters, arms and cylinder**

2. Insert casters into base, set aside.



3. Install arms onto seat using Phillips screws from ARM HARDWARE BAG. **ENSURE CORRECT ORIENTATION**



4. Install back to seat using (3) screws from **BACK HARDWARE BAG** and 5mm Allen Wrench.



5. Install cylinder and dust cover onto chair by simply sliding them in place.



6. Place seat assembly onto base (from step 1); the cylinder will simply slide through the hole in the base.



7. Install optional headrest using the 3mm Allen Wrench and fasteners from the **HEADREST HARDWARE PACK**.



Assembled Chair with Headrest.



CUSTOM SOLUTIONS LLC®
DESIGNED WITH YOU IN MIND