

# Toan Machine Setup Quick Start

## Setup Instructions

### Requirements:

- Mac with Apple Silicon processor
- USB audio interface
- Pedal to capture

For this illustration a Focusrite Scarlett Solo will be used but any interface that can both play and record audio through a 1/4" TS cable will work.

Step 1: Connect the left 'Line Out' audio channel from your interface to your pedal's input jack.

Step 2: Connect your pedal's output to your interface's 1/4" TS input jack.

Step 3: Run Toan Machine and follow the instructions to first record your pedal and then train a model from that recording.

Do not touch any settings on your pedal while recording is in progress.

