



Print template, make sure that scaling is turned off  
 Check template dimensions with ruler  
 Cut out template  
 Glue template to protective film on plexiglass/perspex, spray mount works well  
 Cut outside edges of template, a coping or scroll saw is ideal  
 Drill holes, a drill press is preferable  
 Lightly sand edges to create a frosted effect

2.5 mm = 3/32"  
 3 mm = 1/8"  
 4 mm = 5/32"  
 11.5 mm = 29/64"

Morse It BLE Case		Page Size A4	Scale 1:1	Units mm
February 2, 2021	Project Link: <a href="https://github.com/joshmarvel/MorseltBLE">https://github.com/joshmarvel/MorseltBLE</a>	Created by: Joshua Marvel	Website: <a href="https://M0WYP.com">https://M0WYP.com</a>	