



Print template, make sure that scaling is turned off
 Check template dimensions with ruler
 Cut out template
 Glue template to protective film on plexiglass/perspex, spray mount works well
 Cut outside edges of template, a coping or scroll saw is ideal
 Drill holes, a drill press is preferable
 Lightly sand edges to create a frosted effect

2.5 mm = 3/32"
 3 mm = 1/8"
 4 mm = 5/32"
 11.5 mm = 29/64"

Morse It BLE Case		Page Size A4	Scale 1:1	Units mm
February 2, 2021	Project Link: https://github.com/joshmarvel/MorseltBLE	Created by: Joshua Marvel	Website: https://M0WYP.com	