

Aspen Power Supply Daughterboard

- Remove Aspen from housing.
- Install daughterboard
- Solder daughterboard pins on back of Aspen.
- Clip protruding pins
- Attached BAT+ wire to daughterboard







