

Installation Guide for Crossbars

⚠ [Safety Warning/Caution]

- Please remove the antenna or any accessories on the roof before installation
- Wearing gloves to install is highly recommended
- Do not load or exceed the designated carrying capacity (150lbs/ 68kg)
- Do not over-tighten the knobs or bolts



Step 1:

- [Switch the screws]
Unlock the upper and lower screws, then use the upper screw to lock the bracket, and use the lower screw to lock the clip.



Step 2:

- Slide the clamp on each end of the cross rail, then insert the bar end caps.
- Place the rubber pads on the bottom of the clamps.



Step 3:

- Now you can put the crossbars onto the roof of your vehicle. Make sure the brackets are between the weather strips.



Final

- Use screw driver to lock the clamp, turn clockwise to make it tighten.
- Repeat above steps to the all four clamps.
- Check that the crossbars stay firmly.

