

Installation Guide for Floor Mat

⚠ [Safety Warning/Caution]

- Turn off engine and put the vehicle in Neutral.
- Clean the floor mat with mild soap and water
- Make sure your floorboard is clean and dry.
- Do not use silicone-based or oil treatment on the floor mat.
- Clean the fender panel area of your vehicle
- Cleaning cloth & cleaning liquid (recommended)
- Wearing gloves to install is highly recommended.



- If you have an old floor mat, you can use it as a pattern to get a close/precise-fit for the new floor mat.
- If not, you will have to measure the floorboard first.

Step 1:

- Set the mat in place and lay it flat.
- Remove the mat and trim the rubber edges slowly according to the trim-lines.



Step 2:

- Use scissors to cut the mat and trim the rubber edges slowly according to the trim-lines.
- Remove the excess areas.



Step 3:

- Don't forget to trim mounting tab off of the liner before replacing the new mat to your vehicle.
- You can also trim the rubber edges with a knife.



Step 4:

- Make sure to check that the liner does not interfere with the pedal or brake after replacement.
- Repeat above steps to the other three floor mats.

