Installation Guide for Trunk Mat

Preparation:

- A marker pen, a scissor or knife
- Clean the fender panel area of your vehicle
- Cleaning cloth & cleaning liquid (recommended)
- Wearing gloves to install is highly recommended

[Safety Warning/Caution]

- Turn off the engine and put the vehicle in Neutral.
- Clean the floor mat with mild soap and water before installation.
- Make sure your floorboard is clean and dry.
- Do not use silicone-based or oil treatment onto the floor mat for safety.

Step 1:

If you have an old trunk mat, you can use it as a pattern to get a precise-fit for the new mat. If not, you will have to measure the floorboard first.

Set the mat in place and lay it flat.







Step 2: • Use marker to mark reference trim-lines on the mat.







Step 3: • Remove the mat and trim the rubber edges slowly according to trim-lines.







Step 4: • Remove the excess areas. Place the trunk mat onto the floor board.

 Make sure the rubber floor mat is flat and fit.



FINAL

