

# Installation Guide for Snowboard Carrier

## ⚠ [Safety Warning/Caution]

- Please remove the antenna or any accessories on the roof before installation
- Wearing gloves to install is highly recommended
- Maximum carrying capacity of four snowboards
- Clean the roof of your vehicle (recommended)
- Only install onto the vehicle that has crossbars



## Step 1:

- Place the snowboard carriers onto the crossbars of your vehicle. You can install it symmetrically in the center of your vehicle or closer to one side for easier access.



## Step 2:

- Use the key to unlock the clamps, and press the gray button to open the carriers.



## Step 3:

- Use the cradle straps and the bolts to bind the carriers.



## Step 4:

- Insert the screws into the clamps, then tighten all the screws.
- Make sure the carriers stay firmly.



## Final

- Load your snow boards.
- Press down the top half of the carrier until hear a clip sound, and use the key to lock the carrier.

