

Installation Guide for Splash Guard

⚠ [Safety Warning/Caution]

- Remove all accessories on the body of your vehicle
- Protective car cover is recommended to ensure no damage or scratch was caused to the body during installation.
- Do not over-tighten the screws and bolts.
- Do not wash your vehicle within 24 hours after the installation.
- Tool required: screwdriver, drill, cleaning cloth.



• Preparation:

Turn the steering wheel clockwise all the way, turn off the engine, and lock the handbrake.

Step 1:

- Remove the screws and rivets from the inner fender.
- Clean installation surface with cleaning cloth.



Step 2:

- Position the splash guard on the inner fender to trial fit.
- Drill extra holes if necessary.



Step 3:

- Push the splash guard upward against the body to make sure it is secured properly, and tighten the screws.



Step 4:

- Make sure there are no gaps between the splash guard and body.
- Repeat above steps for the other sides.

