

Installation Guide for Tape-On Window Visor

[Safety Warning/Caution] 

Preparation:

- Turn off the engine and put the vehicle in Neutral, lock the handbrake.
- Avoid exposure to extreme heat and high humidity.
- Clean the window area with dry towels or cleaning wipes.
- Professional installation is always highly recommended.



Step 1:

- We need to trial fit (pre-fit) the window visors onto the window.
- Use an alcohol pad to clean (100% clean) the contact area.
*If the surface is not completely clean, the adhesive will not stick well and the visors will fall off.



Step 2:

- Partially remove (peel off) only 2-3" of the 3M tape on one end, and attach the visor to the window.
- Remove the tape little by little and stick the visor on the window.
*This is easier if you have someone to hold the visors in place when you remove the rest of tape.



Step 3:

- Rub over the top edge and wipe along the visor with a soft cloth, then press down firmly to adhere the tape.



Step 4:

- Repeat above steps to the other three door sides.
(Do not wash the vehicle for 72 hours after installation has been completed.)



Finish