

Lower Frame Assembly




Created by:  
Joshua Vasquez

last edited:  
11/5/2020


SCALE: 1:3

SHEET 1 OF 10

Flip the Lower Frame Assembly Upside Down. Slide each foot's T Nuts under each foot and then tighten all screws.




Note that these inside-corner brackets should face **downwards**. It may be easier to do this step by dangling this end over the edge of a table.



Exploded Upside Down View

Flip the frame right-side up when finished.



Assembled Right-Side Up View

ITEM NO.	DESCRIPTION	QTY.
5	Back Right Foot	1
6	M5 Buttonhead Screw, 10mm long	12
7	Back Left Foot	1
8	Front Right Foot	1
9	Front Left Foot	1
10	Lower Frame	1

#### Corner Foot Installation



Created by:  
Joshua Vasquez


last edited:  
11/5/2020

SCALE: 1:6

SHEET 2 OF 10


Make 3 Assemblies.

These are a 3 piece set.  
Orientation of each piece  
does not matter.



Exploded View

With one hand, compress the coupler  
onto the motor shaft to remove any  
space on the motor shaft. Securely  
screw down the coupler in this  
configuration.



Assembled View

ITEM NO.	DESCRIPTION	QTY.
1	5mm to 8mm flexible plumb coupler	1
2	Nema 17 Stepper Motor	1
3	Z Thrust Bearing Spacer	1
4	5mm Oversize Thrust Bearing	1

### Z Motor Thrust Coupling Assembly



Created by:  
Joshua Vasquez

last edited:  
11/5/2020


SCALE: 1:1

SHEET 3 OF 10

B


A

Apply a dab of threadlock to the tip of the four M3 screws before tightening them down securely.



Exploded View

Wires should stick out in this direction.



Assembled View

ITEM NO.	DESCRIPTION	QTY.
1	M3 Buttonhead Screw, 10mm long	4
2	Back Plate Plate Assembly	1
3	Z Motor Thrust Coupling Assembly	1
4	M3 Washer	4

Back Z Motor Plate Assembly		
	Created by: Joshua Vasquez	last edited: 11/5/2020
	SCALE: 1:1.5	SHEET 4 OF 10

B


A

2

1


Apply a dab of threadlock to the tip of the four M3 screws before tightening them down securely.

B



Exploded View


Motor wires should poke up  
and out from this cavity.



Assembled Top View  
Scale 1:2

B

A



Assembled View

A

ITEM NO.	DESCRIPTION	QTY.
1	M3 Buttonhead Screw, 12mm long	4
3	Z Motor Thrust Coupling Assembly	1
4	M3 Washer	4

2

### Front Left Z Plate Assembly



Created by:  
Joshua Vasquez


last edited:  
11/5/2020

SCALE: 1:1.5

SHEET 5 OF 10


1

Apply a dab of threadlock to the four M3 screws before tightening them down securely.




Exploded View

Motor wires should poke up and out from this cavity.



Assembled Top View  
Scale 1:2



Assembled View

ITEM NO.	DESCRIPTION	QTY.
1	M3 Buttonhead Screw, 12mm long	4
3	Z Motor Thrust Coupling Assembly	1
4	M3 Washer	4

Front Right Z Plate Assembly



Created by:  
Joshua Vasquez

last edited:  
11/5/2020

SCALE: 1:1.5

SHEET 6 OF 10


2

1

Load the Z Motor Plates into the frame to set the spacing of the internal loose extrusions. Push these internal extrusions into the plates and fully tighten the 8 inside corner brackets shown below.

B

B



Top View

A

A

ITEM NO.	DESCRIPTION	
1	Base Frame Assembly with Feet	1
2	Back Z Plate Assembly	1
3	Front Left Z Plate Assembly	1
4	Front Right Z Plate Assembly	1

Internal Extrusion Alignment



Created by:  
Joshua Vasquez


last edited:  
11/5/2020

SCALE: 1:4

SHEET 7 OF 10

2

1



ITEM NO.	DESCRIPTION	
5	Interior Inside Corner Bracket	4

Z Plate Locating		
	Created by: Joshua Vasquez	last edited: 11/5/2020
	SCALE: 1:4	SHEET 8 OF 10

2

1




2

1

Tighten all screws shown below.

B

B



A

A

Top View

ITEM NO.	DESCRIPTION	QTY.
10	M5 Buttonhead Screw, 10mm long	12

Z Plate Tightening



Created by:  
Joshua Vasquez

last edited:  
11/5/2020

SCALE: 1:3

SHEET 9 OF 10

2

1

