

Oregon Oversize/Overweight (OSOW) Permit Process

This document outlines the permit application process, compliance requirements, and routing rules for Oversize/Overweight (OSOW) vehicles operating in the state of Oregon.

Step	Description
1. Application	Apply online via Oregon Trucking Online or through ODOT Motor Carrier Transportation Division.
2. Review	ODOT reviews vehicle dimensions, axle spacing, weights, and load details.
3. Fees	Permit fees depend on weight, dimensions, and permit type (single-trip, continuous trip, or annual).
4. Routing	ODOT assigns a safe route considering bridge limits, clearances, and highway restrictions.
5. Permit Issuance	Permit is issued electronically or via fax/email with all conditions noted.
6. Compliance	Driver must follow permit conditions, including speed limits, time-of-day restrictions, and escort vehicle requirements.

Notes: - Oregon has one of the most detailed OSOW permit systems and requires accurate axle spacing reports. - Continuous trip permits allow movement within Oregon over a set period, subject to route restrictions. - Pilot/escort vehicles are required for certain dimensions and must meet ODOT certification requirements.