


Mount these DNP resistors (R1 & R2) if you want to use USB pins (GPIO19 & GPIO20) only as GPIOs. In this case you should unmount R3 and R4.

Title: <b>ESP32-S3-WROOM-1 Breakout Board</b>		
Designed By: <b>Meysam Parvizi</b>	GitHub: <a href="https://github.com/m3y54m">https://github.com/m3y54m</a>	
Project: <b>PROJECT-ESP32-S3-WROOM-1-BREAKOUT.PjgPcb</b>	Revision: <b>B</b>	
File: <b>ESP32-S3-WROOM-1-BREAKOUT.SchDoc</b>	Date: <b>2022-10-21</b>	
Project Git Hash:	Sheet <b>1</b> of <b>1</b>   Size: <b>A4</b>	
File Git Hash: <b>b64ea4a3a2169956c88e0f2d266e45e5b2e2f6db</b>		

