



(*) Don't use C6 when driving DIM with a 5V PWM signal.
 Replace R1 with a 10k pull-down resistor.