


Remove insulation  
Pre-tin each wire



Put pre-tinned wires together  
Touch with hot soldering iron

