

## II Combine Drugs

---

- Prepare reservoir plates first (run I)
- All files in notes\_II

### vs a)

This version is to create all drug combinations. If that is the intention this script is substantially more efficient regarding tips and waste.

### vs b)

This script is intended to create one combination plate (e.g. to repeat a combination).

## Setup

- Turn off Heat in StoreX (see below)
- Fill Incubator with reservoir plates and reservoirs according to StoreX.csv
- Place tipbox according to locations.csv

## Run

- Start script.
- After adding each drug (takes 20-35 min) you are prompted to replace the tip block.

## Turn of heat StoreX

- Go to evoware
  - Configure
    - Device Information
      - Select Storex
      - Press Settings
        - Set to 20 Degree.
  - save and Exit
- reboot StoreX, Robot and PC