

**You must have a macOS High Sierra installation  
Using Clover in UEFI or ESP  
The WIFI kext will be injected by Clover  
Usage**

**After installation Package,  
plug your USB Wifi and ► Reboot the System.  
After the reboot open Wifi Utility to Desktop**



**Follow all steps**





