

AC current  
signal samples

Take the range of  
every window



Range of signal

Threshold with  
hysteresis



Instantaneous  
binary state

Debouncing counter

Binary state

Feed back  
to control  
hysteresis

