

# WALL MURAL



## PEEL AND STICK WALLPAPER - INSTALLATION

---

***Before you start applying your Cocanva Self Stick Wallpaper, please read these notes and instructions***

- **Take time and work slowly to avoid any mistakes.**
- Prepare a large work area and don't crowd yourself.
- Gently smooth out the paper surface without putting too much pressure on the face of the wallpaper.
- Once removed, the wallpaper cannot be reused. Whilst adhesiveness may still remain, the shape and design will not.
- Self stick wallpaper can be applied onto any type of walls and any furniture such as old wardrobes, cupboards, shelves and tables.

***Lets Start. You will need dry cloth, plastic card or squeegee, craft cutter & scissors.***

---

### 1. PREPARE THE WALLS.

Wash any dirt or dust from the walls and sand smooth any chipped paint. Remove the old wallpaper using a wallpaper remover.

Cracks and irregularities should be filled with suitable filler.

---

### 2. HANG THE WALLPAPER.

Peel the wall sticker from the backing paper.

When the strips is in the correct position, Start from the top left corners of the wal. When the strips is in the correct position, Peel the backing paper and gently smooth down the middle of the wallpaper with a squeegee or dry cloth, ensuring a good butt joint and pattern match, then work outwards towards the edges, removing any air bubbles.

If you need, to leave a few extra inches of paper at the top and bottom for Trimming later.

---

### 3. HANG THE REMAINING PIECES

Hang the second piece, starting at the top. Line up the seams as closely as possible, and try to match the patterns exactly. Smooth out the second piece as in the previous step.

Continue with each piece in the same manner.

---

### 4. TRIM THE EDGES.

Trim away any excess wallpaper using a utility knife or putty knife.

---