

WALL ART CANVAS



HANG YOUR WALL ART - PROCESS

Before you start hanging your Cocanva wall canvas, please read these notes and instructions.

- **Decide on a strategy.**
- The weight, size, and shape of the item you're hanging and the material of your walls both need to be considered first.
- You can mount on tiled walls—you're going to have to drill into the tile wall and use anchors.
- Use skinny nails such as finishing brads (or those tiny ones that come with hanging kits) when hanging a piece on a plaster wall.

Lets Start. You will need hammer, measuring tape, pencil, nails, adhesive hooks, brick clamps, screw & screwdriver. These depend on what kind of wall you are hanging.

STEP 1

There is a semi-science to the art of getting the height of a piece just right—it's called measuring.

To be exact, the center of a framed piece of artwork should be 57 inches above the ground (that being the average human eye level, and the height galleries and museums use to decide where to hang pieces).

STEP 2

Mark that height using a pencil, then measure to find the middle of the wall (from side to side), and mark where the two points meet. That's where the middle of your artwork should go!

STEP 3

Now, measure the distance between the middle of the piece and where it will catch the nail (either where the wire hits when bent to bear weight, or where the saw tooth hanger is).

STEP 4

Measure that difference from your mid-point mark on the wall—that's where the nail (or picture hanger, or wall anchor, or brick clamp) goes.
