

1. Make sure specimen is clean and free of any contaminants.
2. If not completely dry, dry either under heated or non-heated condition for a set time.
3. Mass specimen.
4. Dry specimen further.
5. Mass specimen again.