

## LAB 1 TURN IN QUESTIONS

Oviya Seeniraj, Lily Chen

1. What should my mask be if I want to clear the mode bits of pin PB11?

**0x00C00000**

2. Write the line of code you would use to set PC7 to output mode (Assume the output register is already cleared for you)

**GPIOC->MODER |= 1UL << 14;**

3. Write the line of code you would use to read input data from PC3

**uint32\_t input = (GPIOC->IDR & 1UL<<3) >> 3;**