



# NOTES:

- Solder board in the following order:
  - 1.1 Reflow solder top side using leaded solder paste with stencil
  - 1.2 Hand solder bottom side
- Solid silk-screen square to be used for noting designed output voltage
- Card-edge style board fits into TE Connectivity Mini Crown Edge Connector P3S12 1926155-2

power\_converter

2018-10-28 12:20 PM