



- NOTES:
1. Solder board in following order:
    - 1.1 Reflow solder top surface mounted components except edge connectors
    - 1.2 Hand solder bottom components
    - 1.3 Hand solder remaining top components
      - 1.3.1 Solder edge connectors first
  2. Use LP MINI 891 fuses for F1 through F5
  3. 2oz copper suggested, but not required

carrier\_board  
2018-11-18 10:34 PM