



- NOTES:
1. Solder board in following order:
    - 1.1 Reflow solder top surface mounted components
    - 1.2 Hand solder bottom components
    - 1.3 Hand solder remaining top components
  2. Use LP MINI 891 fuses for F1 through F5