



Patches to Atom board.
 Connect pin 3 of IC44 to VIDCLK pin 10 of IC9 or pin 33 of IC31
 Connect pin 9 of IC44 to B0/DA0 pin 22 of IC 31
 Connect pin 11 of IC44 to MS pin 3 of IC8, or pin 12 of IC31

If removing RAM-ROM board either remove patch wires, or leave pins 3,9 and 11 of IC44 out of the socket

TITLE: RAM-Rombox

Document Number:

REV:

Date: 03/01/2013 02:03:35

Sheet: 2/2