



RevC1: BOOT0 is not on the expansion header
you need to solder a patch wire to the
tactile switch on board

Luckily we can solder on the board edge side.
It's the left leg when looking from the edge.

See <http://bit.ly/1dplugA>

RevC2: See <http://bit.ly/0toQXh> for pinout.