



Ensure cooling coils are suppressing the vapour fumes, with the correct freeboard height set, and the Local Exhaust Ventilation (LEV) is switched-on prior to every use.