

[Log](#)[Share](#)

```
# KERNEL: SI=0 SO=0 Expected=0
# KERNEL: SI=0 SO=0 Expected=0
# KERNEL: SI=1 SO=1 Expected=1
# KERNEL: SI=1 SO=0 Expected=0
# KERNEL: SI=0 SO=0 Expected=0
# KERNEL: SI=0 SO=1 Expected=1
# KERNEL: SI=0 SO=1 Expected=1
# KERNEL: SI=1 SO=0 Expected=0
# KERNEL: SI=0 SO=0 Expected=0
# KERNEL: SI=1 SO=0 Expected=0
# KERNEL: SI=0 SO=1 Expected=1
# RUNTIME: Info: RUNTIME_0068 testbench.sv (16): $finish called.
# KERNEL: Time: 196 ns, Iteration: 0, Instance: /tb, Process: @INITIAL#8_1@.
# KERNEL: stopped at time: 196 ns
# VSIM: Simulation has finished. There are no more test vectors to simulate.
# VSTM: Simulation has finished
```