



Sockets: Use low-profile pin header sockets that ensure that the top of the horizontal PCB will stand 6.8mm above the base of the plug connector.  
Example: Samtec CES-101-01-S-S

Plugs: Use low-profile header pins to avoid overinsertion into SLT socket connectors. A 5mm mating contact length is probably plenty.  
Example: 3M 951101-8622-AR

Forfeited into the public domain with NO WARRANTY  
Tom Stepleton  
stepleton@gmail.com  
London

Sheet: /  
File: SLT\_interconnect.sch

**Title: SLT power interconnect adaptor**

Size: User Date: 2021-08-21  
KiCad E.D.A. kicad (5.1.10)-1

Rev: 00  
Id: 1/1