



Techmates

Automatic Hand Sanitizer Dispenser

User instruction Manuel

1.Installation

1.1 Step 1

Take out the wall mount clamp from package. Two screws , two steel nails and two wall plugs are provided with Automatic Sanitizer Dispenser. If you planning to install Automatic Sanitizer Dispenser to a concrete and If you have a drilling machine you can use screws otherwise please use steel nails.



Wall mount clamp

1.2 Step 2

Put the clamp on wall and mark the holes. Then drill holes on marking and put wall plug

Or

Fix the steel nails to the markings and hang the wall mount clamp.



Clamp fixed on screws

1.3 Step 3

Hang the Automatic Sanitizer Dispenser on the wall mount clamp. Then open the top cap of Automatic Sanitizer Dispenser by pull up the cap.



1.4 Step 4

Fill the sanitizer to the tank of Automatic Sanitizer Dispenser. Not necessary to fill to top of the tank. Then close the cap of Automatic Sanitizer Dispenser

Caution

Only use the sanitizer with low viscosity in Automatic Sanitizer Dispenser.

1.5 Step 5

Plug the main chord to the standard wall socket. And then turn on the switch of wall socket.

Then wait till the red indicator become green.

Now the Automatic Sanitizer Dispenser is ready to work.

Caution

Only place your hand when the Indicator is Green

Enjoy the touchless world

Techmates is an initiative from Department of Electronics, Government College Tanur, Malappuram

All rights reserved to Techmates

<https://techmatesproducts.github.io>