



# **Techmates**

## **Automatic Hand Sanitizer Dispenser**

### **User instruction Manuel**

## **1.Installation**

### **1.1 Step 1**

Take out the wall mount clamp from package. Two screws , two steel nails and two wall plugs are provided with Automatic Sanitizer Dispenser. If you planning to install Automatic Sanitizer Dispenser to a concrete and If you have a drilling machine you can use screws otherwise please use steel nails.



Wall mount clamp

## 1.2 Step 2

Put the clamp on wall and mark the holes. Then drill holes on marking and put wall plug

**Or**

Fix the steel nails to the markings and hang the wall mount clamp.



Clamp fixed on screws

## 1.3 Step 3

Hang the Automatic Sanitizer Dispenser on the wall mount clamp. Then open the top cap of Automatic Sanitizer Dispenser by pull up the cap.



## 1.4 Step 4

Fill the sanitizer to the tank of Automatic Sanitizer Dispenser. Not necessary to fill to top of the tank. Then close the cap of Automatic Sanitizer Dispenser

### ***Caution***

Only use the sanitizer with low viscosity in Automatic Sanitizer Dispenser.

## 1.5 Step 5

Plug the main chord to the standard wall socket. And then turn on the switch of wall socket.

**Then wait till the red indicator become green.**

Now the Automatic Sanitizer Dispenser is ready to work.

## **Caution**

**Only place your hand when the Indicator is Green**

*Enjoy the touchless world*

*All rights reserved to Techmates*

<https://techmatesproducts.github.io>