



Board Notes:

- Place connectors on opposite sides of the board
- Use a 4 layer stackup, 50 ohm single ended
- Add ground isolation between every single net

<u>1</u>	FID
<u>1</u>	FID
<u>1</u>	FID

Title			
Size Letter	Number		Revision
Date:	5/09/2023	Sheet of	
File:	E:\Data\...\CADDX.SchDoc	Drawn By:	