



1. SOLDER A LINK BETWEEN RST AND XPD_DCDC PINS
2. REMOVE BUT-IN LED TO SAVE POWER

